

Following example is setting start DO1 DI1 button switch lock setting process:

SY260NT Set DI1 door button to launch the DO1 relay lock		
Enter key	controller for LCD display	Note
MENU	Login	
EN	Password [1234_ _ _ _]	Wait for the password input
EN	Master OK	Red light blinking, have entered the login status
▼*2	System	
EN	System Process	
▼*2	Door Process	
EN	Door Relay	Entering the gate area relay set menu
EN	Door Door : [1]	[1] District 1
EN	Door ID : [0] CH : [01]	Set the start relay channel ID:[0] controller DO 1~8 that enable external expansion module is enabled. CH:[01] enables 01 channel
EN	Time [005] sec	Set the relay start time in seconds 5 seconds
EN	Door Relay	According to the EN button to confirm setting
▼*2	Door Button	Set the door button menu
EN	Door Door : [1]	[1] District 1
EN	Door ID : [0] CH : [01]	Set the entry point to trigger channel ID:[0] DI enabled controllers. 1~8 external expansion module is enabled. CH:[01] enables 01 channel
EN	Door Button	According to the EN button to confirm setting
CLR*3	2007/12/30 17:52:53	Set finished, back to the date and time options

NO On power open door wiring diagram:

NC Off Power open door wiring diagram:

